



Quick start guide

Hardware overview



- Dimensions 88x81x310 (mm)
- **Weight** 530g

- 4 Power adapter 5V/2.4A
 - **Charging** up to five devices



1. Connect the USB-C cable to the station and plug it into a power socket using the included adapter (min. 5V and 2.4A).

2. Place the card reader on one of the charging pillars, until it snaps into place.

3. Check if the lights starts blinking to make sure the reader is placed correctly. The lights turn off when the reader is fully charged.

Mounting on a wall

Choose your desired location and place two screws with a spacing of 150 mm, using the keyhole slots on the back of the station.

Align the keyholes to the screws and hang the station. Make sure that the station locks securely into the keyholes.

