


## Dock + Printer


Give your reader a home on your counter and print receipts


Quick start guide

## Hardware overview



- Dimensions 67x83x114 (mm)
- 🛆 Weight 372g
- Wi-Fi to connect to printer
- Paper roll size 57x30 (mm)
- **Power adapter** 5V/2.4A
- USB-C to connect to device






**1.** Check if all the cables are connected, as described on the previous page.

**2.** Fasten the snap plate in the desired position using the included adhesive strip or screw.

**3.** Place the dock on top of the plate and push down gently until the dock snaps into place.

**4.** Place the card reader in the dock.

## Replacing the paper roll



**1.** Press firmly on the bottom side of the paper hatch.

**2.** Place a new paper roll in the compartment.

**3.** Make sure the coated paper side is up and the paper aligns to the printing head.

**4.** Close the paper hatch and make sure it snaps into place.